

IMPORTANT: READ INSTRUCTIONS BEFORE STARTING INSTALLATION

INSTALLATION INSTRUCTIONS

1. Fully close sliding doors.
2. Locate strike(C) on edge of inner door(D) so that locking unit(A) is installed on lower edge of outer door(B) slipping tongue(E) fits thru center hole of strike unit (C) as indicated.
3. Mark top and bottom holes for strike unit (C).
4. Using 1/8" drill bit, drill holes where marked and install strike unit with 2 self-tapping metal screws furnished. Drill only enough to penetrate door frame skin. **Do not touch glass with drill bit.**
5. Locate locking unit on bottom edge of outer door(B) as described in step 2 and mark 3 holes on stationary half of locking unit(A).
6. Drill three (3) holes and install locking unit as described in step 4.

NOTE: PART (A) SHOULD FIT SNUG AGAINST PART (C).

